

1500 LB CHART HDXL

FRONT WHEEL LOAD (LBS)	LOCATOR POSITION	WEIGHT CARRIED (LBS)	TONGUE LOAD (LBS)
1500 LBS	1	300 LBS	318
	6		263
	12	AT CENTER	197
	18	OF TRACKS	131
	22		88
	26		44
	30		0
1500 LBS	1	400 LBS	362
	6		307
	12	AT CENTER	253
	18	OF TRACKS	171
	22		117
	26		62
	30		8
1500 LBS	1	500 LBS	459
	6		390
	12	AT CENTER	309
	18	OF TRACKS	227
	22		172
	26		118
	30		63
1500 LBS	1	600 LBS	514
	6		446
	12	AT CENTER	364
	18	OF TRACKS	282
	22		228
	26		173
	30		119
1500 LBS	1	700 LBS	570
	6		501
	12	AT CENTER	420
	18	OF TRACKS	338
	22		283
	26		229
	30		174
1500 LBS	1	800 LBS	625
	6		557
	12	AT CENTER	475
	18	OF TRACKS	393
	22		339
	26		284
	30		230

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

1500 LB CHART HDXL

FRONT WHEEL LOAD (LBS)	LOCATOR POSITION	WEIGHT CARRIED (LBS)	TONGUE LOAD (LBS)
1500 LBS	1	1000 LBS	629
	6		575
	12	AT CENTER	509
	18	OF TRACKS	443
	22		399
	26		356
	30		312
1500 LBS	1	1200 LBS	718
	6		664
	12	AT CENTER	598
	18	OF TRACKS	532
	22		488
	26		445
	30		401
1500 LBS	1	1400 LBS	807
	6		753
	12	AT CENTER	687
	18	OF TRACKS	621
	22		577
	26		534
	30		490
1500 LBS	1	1600 LBS	896
	6		842
	12	AT CENTER	776
	18	OF TRACKS	710
	22		667
	26		623
	30		579
1500 LBS	1	1800 LBS	986
	6		931
	12	AT CENTER	865
	18	OF TRACKS	799
	22		756
	26		712
	30		668

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

1600 LB CHART HDXL

FRONT	LOCATOR	WEIGHT	TONGUE
-------	---------	--------	--------

WHEEL LOAD (LBS)	POSITION	CARRIED (LBS)	LOAD (LBS)
1600 LBS	1	300 LBS	317
	6		259
	12	AT CENTER	188
	18	OF TRACKS	118
	22		72
	26		25
	30		-22
1600 LBS	1	400 LBS	361
	6		303
	12	AT CENTER	242
	18	OF TRACKS	155
	22		97
	26		39
	30		-20
1600 LBS	1	500 LBS	458
	6		385
	12	AT CENTER	298
	18	OF TRACKS	210
	22		152
	26		94
	30		36
1600 LBS	1	600 LBS	513
	6		440
	12	AT CENTER	353
	18	OF TRACKS	266
	22		208
	26		150
	30		91
1600 LBS	1	700 LBS	569
	6		496
	12	AT CENTER	409
	18	OF TRACKS	321
	22		263
	26		205
	30		147
1600 LBS	1	800 LBS	624
	6		551
	12	AT CENTER	464
	18	OF TRACKS	377
	22		319
	26		260
	30		202

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**1600 LB CHART
HDXL**

FRONT WHEEL LOAD (LBS)	LOCATOR POSITION	WEIGHT CARRIED (LBS)	TONGUE LOAD (LBS)
---------------------------	---------------------	-------------------------	----------------------

1600 LBS	1	1000 LBS	629
	6		570
	12	AT CENTER	500
	18	OF TRACKS	430
	22		383
	26		337
	30		290
1600 LBS	1	1200 LBS	718
	6		659
	12	AT CENTER	589
	18	OF TRACKS	519
	22		472
	26		426
	30		379
1600 LBS	1	1400 LBS	807
	6		748
	12	AT CENTER	678
	18	OF TRACKS	608
	22		561
	26		515
	30		468
1600 LBS	1	1600 LBS	896
	6		837
	12	AT CENTER	767
	18	OF TRACKS	697
	22		650
	26		604
	30		557
1600 LBS	1	1800 LBS	985
	6		926
	12	AT CENTER	856
	18	OF TRACKS	786
	22		740
	26		693
	30		646

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**1700 LB CHART
HDXL**

FRONT WHEEL LOAD (LBS)	LOCATOR POSITION	WEIGHT CARRIED (LBS)	TONGUE LOAD (LBS)
1600 LBS	1	300 LBS	317
	6		259
	12	AT CENTER	188

	18	OF TRACKS	118
	22		72
	26		25
	30		-22
1600 LBS	1	400 LBS	361
	6		303
	12	AT CENTER	233
	18	OF TRACKS	163
	22		116
	26		39
	30		-20
1600 LBS	1	500 LBS	406
	6		348
	12	AT CENTER	277
	18	OF TRACKS	207
	22		161
	26		114
	30		67
1600 LBS	1	600 LBS	450
	6		392
	12	AT CENTER	322
	18	OF TRACKS	252
	22		205
	26		159
	30		112
1600 LBS	1	700 LBS	495
	6		437
	12	AT CENTER	367
	18	OF TRACKS	296
	22		250
	26		203
	30		156
1600 LBS	1	800 LBS	540
	6		481
	12	AT CENTER	411
	18	OF TRACKS	341
	22		294
	26		248
	30		201

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**1700 LB CHART
HDXL**

FRONT WHEEL LOAD (LBS)	LOCATOR POSITION	WEIGHT CARRIED (LBS)	TONGUE LOAD (LBS)
1600 LBS	1	1000 LBS	629
	6		570
	12	AT CENTER	500
	18	OF TRACKS	430

	22		383
	26		337
	30		290
1600 LBS	1	1200 LBS	718
	6		659
	12	AT CENTER	589
	18	OF TRACKS	519
	22		472
	26		426
	30		379
1600 LBS	1	1400 LBS	807
	6		748
	12	AT CENTER	678
	18	OF TRACKS	608
	22		561
	26		515
	30		468
1600 LBS	1	1600 LBS	896
	6		837
	12	AT CENTER	767
	18	OF TRACKS	697
	22		650
	26		604
	30		557
1600 LBS	1	1800 LBS	985
	6		926
	12	AT CENTER	856
	18	OF TRACKS	786
	22		740
	26		693
	30		646

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**1800 LB CHART
HDXL**

FRONT WHEEL LOAD (LBS)	LOCATOR POSITION	WEIGHT CARRIED (LBS)	TONGUE LOAD (LBS)
1800 LBS	1	300 LBS	315
	6		250
	12	AT CENTER	171
	18	OF TRACKS	92
	22		40
	26		-13
	30		-66
1800 LBS	1	400 LBS	360

	6		294
	12	AT CENTER	215
	18	OF TRACKS	137
	22		84
	26		-9
	30		-74
1800 LBS	1	500 LBS	404
	6		339
	12	AT CENTER	260
	18	OF TRACKS	181
	22		129
	26		76
	30		23
1800 LBS	1	600 LBS	449
	6		383
	12	AT CENTER	304
	18	OF TRACKS	226
	22		173
	26		121
	30		68
1800 LBS	1	700 LBS	494
	6		428
	12	AT CENTER	349
	18	OF TRACKS	270
	22		218
	26		165
	30		113
1800 LBS	1	800 LBS	538
	6		472
	12	AT CENTER	394
	18	OF TRACKS	315
	22		262
	26		210
	30		157

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**1800 LB CHART
HDXL**

FRONT WHEEL LOAD (LBS)	LOCATOR POSITION	WEIGHT CARRIED (LBS)	TONGUE LOAD (LBS)
1800 LBS	1	1000 LBS	627
	6		561
	12	AT CENTER	483
	18	OF TRACKS	404
	22		351
	26		299
	30		246
1800 LBS	1	1200 LBS	716
	6		650
	12	AT CENTER	572

	18	OF TRACKS	493
	22		440
	26		388
	30		335
1800 LBS	1	1400 LBS	805
	6		740
	12	AT CENTER	661
	18	OF TRACKS	582
	22		529
	26		477
	30		424
1800 LBS	1	1600 LBS	894
	6		829
	12	AT CENTER	750
	18	OF TRACKS	671
	22		618
	26		566
	30		513
1800 LBS	1	1800 LBS	983
	6		918
	12	AT CENTER	839
	18	OF TRACKS	760
	22		707
	26		655
	30		602

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**1900 LB CHART
HDXL**

FRONT	LOCATOR	WEIGHT	TONGUE
WHEEL LOAD (LBS)	POSITION	CARRIED (LBS)	LOAD (LBS)
1900 LBS	1	300 LBS	315
	6		245
	12	AT CENTER	162
	18	OF TRACKS	79
	22		23
	26		-32
	30		-87
1900 LBS	1	400 LBS	359
	6		290
	12	AT CENTER	207
	18	OF TRACKS	123
	22		68

	26		-32
	30		-101
1900 LBS	1	500 LBS	404
	6		334
	12	AT CENTER	251
	18	OF TRACKS	168
	22		113
	26		57
	30		2
1900 LBS	1	600 LBS	448
	6		379
	12	AT CENTER	296
	18	OF TRACKS	213
	22		157
	26		102
	30		46
1900 LBS	1	700 LBS	493
	6		423
	12	AT CENTER	340
	18	OF TRACKS	257
	22		202
	26		146
	30		91
1900 LBS	1	800 LBS	537
	6		468
	12	AT CENTER	385
	18	OF TRACKS	302
	22		246
	26		191
	30		135

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**1900 LB CHART
HDXL**

FRONT WHEEL LOAD (LBS)	LOCATOR POSITION	WEIGHT CARRIED (LBS)	TONGUE LOAD (LBS)
1900 LBS	1	1000 LBS	626
	6		557
	12	AT CENTER	474
	18	OF TRACKS	391
	22		335
	26		280
	30		224
1900 LBS	1	1200 LBS	715
	6		646
	12	AT CENTER	563
	18	OF TRACKS	480
	22		424
	26		369

	30		313
1900 LBS	1	1400 LBS	804
	6		735
	12	AT CENTER	652
	18	OF TRACKS	569
	22		513
	26		458
	30		402
1900 LBS	1	1600 LBS	894
	6		824
	12	AT CENTER	741
	18	OF TRACKS	658
	22		602
	26		547
	30		491
1900 LBS	1	1800 LBS	983
	6		913
	12	AT CENTER	830
	18	OF TRACKS	747
	22		691
	26		636
	30		580

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**2000 LB CHART
HDXL**

FRONT	LOCATOR	WEIGHT	TONGUE
WHEEL LOAD (LBS)	POSITION	CARRIED (LBS)	LOAD (LBS)
2000 LBS	1	300 LBS	314
	6		241
	12	AT CENTER	153
	18	OF TRACKS	66
	22		7
	26		-51
	30		-109
2000 LBS	1	400 LBS	359
	6		286
	12	AT CENTER	198
	18	OF TRACKS	110
	22		52
	26		-56
	30		-129
2000 LBS	1	500 LBS	403

	6		330
	12	AT CENTER	242
	18	OF TRACKS	155
	22		96
	26		38
	30		-20
2000 LBS	1	600 LBS	448
	6		375
	12	AT CENTER	287
	18	OF TRACKS	199
	22		141
	26		83
	30		24
2000 LBS	1	700 LBS	492
	6		419
	12	AT CENTER	331
	18	OF TRACKS	244
	22		186
	26		127
	30		69
2000 LBS	1	800 LBS	537
	6		464
	12	AT CENTER	376
	18	OF TRACKS	288
	22		230
	26		172
	30		113

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**2000 LB CHART
HDXL**

FRONT	LOCATOR	WEIGHT	TONGUE
WHEEL LOAD (LBS)	POSITION	CARRIED (LBS)	LOAD (LBS)
2000 LBS	1	1000 LBS	626
	6		553
	12	AT CENTER	465
	18	OF TRACKS	377
	22		319
	26		261
	30		202
2000 LBS	1	1200 LBS	715
	6		642
	12	AT CENTER	554
	18	OF TRACKS	467
	22		408
	26		350
	30		291
2000 LBS	1	1400 LBS	804
	6		731

	12	AT CENTER	643
	18	OF TRACKS	556
	22		497
	26		439
	30		380
2000 LBS	1	1600 LBS	893
	6		820
	12	AT CENTER	732
	18	OF TRACKS	645
	22		586
	26		528
	30		469
2000 LBS	1	1800 LBS	982
	6		909
	12	AT CENTER	821
	18	OF TRACKS	734
	22		675
	26		617
	30		559

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**2250 LB CHART
HDXL**

FRONT WHEEL LOAD (LBS)	LOCATOR POSITION	WEIGHT CARRIED (LBS)	TONGUE LOAD (LBS)
2250 LBS	1	300 LBS	312
	6		230
	12	AT CENTER	131
	18	OF TRACKS	33
	22		-33
	26		-98
	30		-164
2250 LBS	1	400 LBS	357
	6		275
	12	AT CENTER	176
	18	OF TRACKS	77
	22		12
	26		-115
	30		-197
2250 LBS	1	500 LBS	401
	6		319
	12	AT CENTER	221
	18	OF TRACKS	122
	22		56

	26		-9
	30		-75
2250 LBS	1	600 LBS	446
	6		364
	12	AT CENTER	265
	18	OF TRACKS	167
	22		101
	26		35
	30		-31
2250 LBS	1	700 LBS	490
	6		408
	12	AT CENTER	310
	18	OF TRACKS	211
	22		145
	26		80
	30		14
2250 LBS	1	800 LBS	535
	6		453
	12	AT CENTER	354
	18	OF TRACKS	256
	22		190
	26		124
	30		59

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**2250 LB CHART
HDXL**

FRONT	LOCATOR	WEIGHT	TONGUE
WHEEL LOAD (LBS)	POSITION	CARRIED (LBS)	LOAD (LBS)
2250 LBS	1	1000 LBS	624
	6		542
	12	AT CENTER	443
	18	OF TRACKS	345
	22		279
	26		213
	30		148
2250 LBS	1	1200 LBS	713
	6		631
	12	AT CENTER	532
	18	OF TRACKS	434
	22		368
	26		302
	30		237
2250 LBS	1	1400 LBS	802
	6		720
	12	AT CENTER	621
	18	OF TRACKS	523
	22		457
	26		391
	30		326

2250 LBS	1	1600 LBS	891
	6		809
	12	AT CENTER	710
	18	OF TRACKS	612
	22		546
	26		480
	30		415
2250 LBS	1	1800 LBS	980
	6		898
	12	AT CENTER	799
	18	OF TRACKS	701
	22		635
	26		569
	30		504

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**2500 LB CHART
HDXL**

FRONT	LOCATOR	WEIGHT	TONGUE
WHEEL LOAD (LBS)	POSITION	CARRIED (LBS)	LOAD (LBS)
2500 LBS	1	300 LBS	310
	6		219
	12	AT CENTER	110
	18	OF TRACKS	0
	22		-73
	26		-146
	30		-219
2500 LBS	1	400 LBS	355
	6		264
	12	AT CENTER	154
	18	OF TRACKS	45
	22		-28
	26		-174
	30		-265
2500 LBS	1	500 LBS	399
	6		308
	12	AT CENTER	199
	18	OF TRACKS	89
	22		16
	26		-57
	30		-130
2500 LBS	1	600 LBS	444
	6		353
	12	AT CENTER	243

	18	OF TRACKS	134
	22		61
	26		-12
	30		-85
2500 LBS	1	700 LBS	488
	6		397
	12	AT CENTER	288
	18	OF TRACKS	178
	22		105
	26		32
	30		-41
2500 LBS	1	800 LBS	533
	6		442
	12	AT CENTER	332
	18	OF TRACKS	223
	22		150
	26		77
	30		4

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**2500 LB CHART
HDXL**

FRONT	LOCATOR	WEIGHT	TONGUE
WHEEL LOAD (LBS)	POSITION	CARRIED (LBS)	LOAD (LBS)
2500 LBS	1	1000 LBS	622
	6		531
	12	AT CENTER	421
	18	OF TRACKS	312
	22		239
	26		166
	30		93
2500 LBS	1	1200 LBS	711
	6		620
	12	AT CENTER	510
	18	OF TRACKS	401
	22		328
	26		255
	30		182
2500 LBS	1	1400 LBS	800
	6		709
	12	AT CENTER	599
	18	OF TRACKS	490
	22		417
	26		344
	30		271
2500 LBS	1	1600 LBS	889
	6		798
	12	AT CENTER	688
	18	OF TRACKS	579

	22		506
	26		433
	30		360
2500 LBS	1	1800 LBS	978
	6		887
	12	AT CENTER	777
	18	OF TRACKS	668
	22		595
	26		522
	30		449

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**2750 LB CHART
HDXL**

FRONT WHEEL LOAD (LBS)	LOCATOR POSITION	WEIGHT CARRIED (LBS)	TONGUE LOAD (LBS)
2750 LBS	1	300 LBS	309
	6		208
	12	AT CENTER	88
	18	OF TRACKS	-33
	22		-113
	26		-193
	30		-274
2750 LBS	1	400 LBS	353
	6		253
	12	AT CENTER	132
	18	OF TRACKS	12
	22		-69
	26		-233
	30		-333
2750 LBS	1	500 LBS	398
	6		297
	12	AT CENTER	177
	18	OF TRACKS	56
	22		-24
	26		-104
	30		-185
2750 LBS	1	600 LBS	442
	6		342
	12	AT CENTER	221
	18	OF TRACKS	101
	22		21
	26		-60
	30		-140

2750 LBS	1	700 LBS	487
	6		386
	12	AT CENTER	266
	18	OF TRACKS	145
	22		65
	26		-15
	30		-96
2750 LBS	1	800 LBS	531
	6		431
	12	AT CENTER	310
	18	OF TRACKS	190
	22		110
	26		29
	30		-51

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**2750 LB CHART
HDXL**

FRONT	LOCATOR	WEIGHT	TONGUE
WHEEL LOAD (LBS)	POSITION	CARRIED (LBS)	LOAD (LBS)
2750 LBS	1	1000 LBS	620
	6		520
	12	AT CENTER	399
	18	OF TRACKS	279
	22		199
	26		118
	30		38
2750 LBS	1	1200 LBS	709
	6		609
	12	AT CENTER	488
	18	OF TRACKS	368
	22		288
	26		207
	30		127
2750 LBS	1	1400 LBS	798
	6		698
	12	AT CENTER	577
	18	OF TRACKS	457
	22		377
	26		296
	30		216
2750 LBS	1	1600 LBS	887
	6		787
	12	AT CENTER	667
	18	OF TRACKS	546
	22		466
	26		386
	30		305

2750 LBS	1	1800 LBS	976
	6		876
	12	AT CENTER	756
	18	OF TRACKS	635
	22		555
	26		475
	30		394

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**3000 LB CHART
HDXL**

FRONT	LOCATOR	WEIGHT	TONGUE
WHEEL LOAD (LBS)	POSITION	CARRIED (LBS)	LOAD (LBS)
3000 LBS	1	300 LBS	307
	6		197
	12	AT CENTER	66
	18	OF TRACKS	-66
	22		-153
	26		-241
	30		-328
3000 LBS	1	400 LBS	351
	6		242
	12	AT CENTER	110
	18	OF TRACKS	-21
	22		-109
	26		-292
	30		-401
3000 LBS	1	500 LBS	396
	6		286
	12	AT CENTER	155
	18	OF TRACKS	23
	22		-64
	26		-152
	30		-239
3000 LBS	1	600 LBS	440
	6		331
	12	AT CENTER	199
	18	OF TRACKS	68
	22		-20
	26		-107
	30		-195
3000 LBS	1	700 LBS	485
	6		375
	12	AT CENTER	244

	18	OF TRACKS	113
	22		25
	26		-63
	30		-150
3000 LBS	1	800 LBS	529
	6		420
	12	AT CENTER	288
	18	OF TRACKS	157
	22		69
	26		-18
	30		-106

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**3000 LB CHART
HDXL**

FRONT	LOCATOR	WEIGHT	TONGUE
WHEEL LOAD (LBS)	POSITION	CARRIED (LBS)	LOAD (LBS)
3000 LBS	1	1000 LBS	618
	6		509
	12	AT CENTER	377
	18	OF TRACKS	246
	22		159
	26		71
	30		-17
3000 LBS	1	1200 LBS	707
	6		598
	12	AT CENTER	467
	18	OF TRACKS	335
	22		248
	26		160
	30		72
3000 LBS	1	1400 LBS	796
	6		687
	12	AT CENTER	556
	18	OF TRACKS	424
	22		337
	26		249
	30		161
3000 LBS	1	1600 LBS	886
	6		776
	12	AT CENTER	645
	18	OF TRACKS	513
	22		426
	26		338
	30		250
3000 LBS	1	1800 LBS	975
	6		865
	12	AT CENTER	734

	18	OF TRACKS	602
	22		515
	26		427
	30		340

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**3250 LB CHART
HDXL**

FRONT	LOCATOR	WEIGHT	TONGUE
WHEEL LOAD (LBS)	POSITION	CARRIED (LBS)	LOAD (LBS)
3250 LBS	1	300 LBS	243
	6		95
	12	AT CENTER	-82
	18	OF TRACKS	-260
	22		-378
	26		-496
	30		-614
3250 LBS	1	400 LBS	292
	6		144
	12	AT CENTER	-33
	18	OF TRACKS	-210
	22		-329
	26		-447
	30		-565
3250 LBS	1	500 LBS	341
	6		193
	12	AT CENTER	16
	18	OF TRACKS	-161
	22		-280
	26		-398
	30		-516
3250 LBS	1	600 LBS	390
	6		242
	12	AT CENTER	65
	18	OF TRACKS	-112
	22		-230
	26		-349
	30		-467
3250 LBS	1	700 LBS	439
	6		291
	12	AT CENTER	114
	18	OF TRACKS	-63
	22		-181
	26		-300

	30		-418
3250 LBS	1	800 LBS	488
	6		340
	12	AT CENTER	163
	18	OF TRACKS	-14
	22		-132
	26		-250
	30		-369

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**3250 LB CHART
HDXL**

FRONT WHEEL LOAD (LBS)	LOCATOR POSITION	WEIGHT CARRIED (LBS)	TONGUE LOAD (LBS)
3250 LBS	1	1000 LBS	621
	6		503
	12	AT CENTER	360
	18	OF TRACKS	218
	22		123
	26		28
	30		-67
3250 LBS	1	1200 LBS	713
	6		594
	12	AT CENTER	452
	18	OF TRACKS	310
	22		215
	26		120
	30		25
3250 LBS	1	1400 LBS	805
	6		686
	12	AT CENTER	544
	18	OF TRACKS	402
	22		307
	26		212
	30		117
3250 LBS	1	1600 LBS	897
	6		778
	12	AT CENTER	636
	18	OF TRACKS	494
	22		399
	26		304
	30		209
3250 LBS	1	1800 LBS	989
	6		870
	12	AT CENTER	728
	18	OF TRACKS	586
	22		491
	26		396
	30		301

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**3500 LB CHART
HDXL**

FRONT WHEEL LOAD (LBS)	LOCATOR POSITION	WEIGHT CARRIED (LBS)	TONGUE LOAD (LBS)
3500 LBS	1	300 LBS	278
	6		150
	12	AT CENTER	-3
	18	OF TRACKS	-157
	22		-259
	26		-361
	30		-463
3500 LBS	1	400 LBS	317
	6		189
	12	AT CENTER	36
	18	OF TRACKS	-117
	22		-219
	26		-322
	30		-424
3500 LBS	1	500 LBS	357
	6		229
	12	AT CENTER	76
	18	OF TRACKS	-78
	22		-180
	26		-282
	30		-384
3500 LBS	1	600 LBS	396
	6		268
	12	AT CENTER	115
	18	OF TRACKS	-38
	22		-141
	26		-243
	30		-345
3500 LBS	1	700 LBS	435
	6		308
	12	AT CENTER	154
	18	OF TRACKS	1
	22		-101
	26		-203
	30		-306
3500 LBS	1	800 LBS	475

	6		347
	12	AT CENTER	194
	18	OF TRACKS	40
	22		-62
	26		-164
	30		-266

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.

**3500 LB CHART
HDXL**

FRONT WHEEL LOAD (LBS)	LOCATOR POSITION	WEIGHT CARRIED (LBS)	TONGUE LOAD (LBS)
3500 LBS	1	1000 LBS	619
3500 LBS	6		492
	12	AT CENTER	338
	18	OF TRACKS	185
	22		83
	26		-19
	30		-122
	1	1200 LBS	711
	6		584
	12	AT CENTER	430
	18	OF TRACKS	277
	22		175
	26		73
	30		-30
	3500 LBS	1	1400 LBS
	6		676
	12	AT CENTER	522
	18	OF TRACKS	369
	22		267
	26		165
	30		62
	3500 LBS	1	1600 LBS
	6		767
	12	AT CENTER	614
	18	OF TRACKS	461
	22		359
	26		257
	30		154
3500 LBS	1	1800 LBS	987
	6		859
	12	AT CENTER	706
	18	OF TRACKS	553
	22		451

	26		349
	30		246

VERIFY ALL SETTINGS BY ACTUAL WEIGHING WHEN PREPARING TO TOW

Tongue weights marked in **RED** are not acceptable, as this would be an upwards force at the Hitch. Consult your Tow vehicle manufacturer for tongue weight limits. You are responsible for not exceeding the rated GVWR of your Tandem Tow Trailer. Towing with a load above the GVWR of a Tandem Tow Trailer voids the warranty. This chart is only a suggested guide to setting the tongue load. It is not to be used to comply with the weight limits of the Tandem Tow Trailer or the tow vehicle.